



- Coding plug (R 29) . . . . . Remove (54—577)  
Ohmmeter . . . . . Connect (refer to table)  
Resistance values . . . . . Check (refer to table), replace coding plug (R 29) if values are deviating.
- a Production date  
b Part number  
c Designation of jack

Test table — resistance values

Part number	Connection ohmmeter on jack designation						
	A—D	B—E	D—C	D—H	E—D	E—F	E—G
005 545 07 32	$\infty$	1470—1530 k $\Omega$	0.01—15 $\Omega$	3.21—3.27 k $\Omega$	$\infty$	26.2—27.2 k $\Omega$	501—521 k $\Omega$
005 545 08 32	$\infty$	1470—1530 k $\Omega$	0.01—15 $\Omega$	1.18—2.02 k $\Omega$	$\infty$	25.2—27.2 k $\Omega$	501—521 k $\Omega$

Conventional tool

Multimeter	SUN	DMM—5
------------	-----	-------